



**Normal Operation:**

- Water enters through rear inlet (from bermed area).
- Water flows from rear chamber into front left and right chambers.
- Water passes through filter cartridges, removing contaminants.
- Clean water passes through the lower holes into the center chamber.
- Clean water leaves Berm Barrier through outlet in front panel.

(Front and side panel omitted for clarity on this drawing.)

DRAWN Hayden Trattner	15/12/2011	Petro Barrier Systems Inc.		
CHECKED		TITLE		
QA		Berm Barrier		
MFG				
APPROVED		SIZE	DWG NO	REV
		C	Normal Flow Diagram	
		SCALE	SHEET 1 OF 1	